

## BSC Race Management – Support Boat Starting Instructions

### **Mark I – Center Console Whaler Starting Instructions**

1. Check Fuel and open vent on fill cap
2. Repeatedly squeeze fuel line bulb until firm to squeeze
3. Insert ignition key and turn until motor starts
4. Press black button at bottom center of the control level and adjust lever to idle
5. Look for stream of water from motor – if not stream, turn off ignition switch

### **Mark II – Side Console Whaler Starting Instructions**

1. Check Fuel and open vent on fill cap
2. Repeatedly squeeze fuel line bulb until firm to squeeze
3. Remove black cap on top of motor and cap off of the oil reservoir
4. Fill oil reservoir with oil from the container if needed (holds about a 3hr supply)
5. Turn on **RED** battery switch in stern of boat
6. Advance the idle level to **full up** position (choke position)
7. Insert and turn key for 5 seconds
8. Move idle level to half up position
9. Turn key. Motor should start. Adjust idle.
10. Look for small stream of water from motor. If no stream of water from motor, turn off and do not use.
11. We returned to slip at end of use, TURN OFF THE **RED** BATTERY SWITCH